

5 in 1

SAFETY EXHAUST COUPLER

One Coupling does it all!

The 5-in-1 Safety Exhaust Coupler reduces the possibility of injury to nearby personnel or damage to surrounding equipment from a whipping hose that is disconnected while pressurized air is still in the line. This coupler is designed to remain connected to the plug until the downstream air is completely bled off.



* Please Note: In 3/8" and 1/2" body sizes, the Safety Exhaust Coupler works ONLY with the Industrial and Automotive Interchanges.

- Easily connects under zero pressure
- Safely disconnects without hose whip

Easily & Safely Connects with All Major Interchanges

- Industrial
- Aro
- Automotive (Tru-Flate)
- Euro (Megaflow)
- Lincoln



COILHOSE PNEUMATICS
 19 Kimberly Road
 East Brunswick, NJ 08816

Ph: 732 390 8480 Fax: 732 390 9693
 info@coilhose.com

| MODEL NUMBER | ITEM DESCRIPTION |
|-----------------------|------------------|
| 1/4" BODY SIZE | |
| 150USE | 1/4" FPT |
| 152USE | 1/4" MPT |
| 153USE | 1/4" Hose Barb |
| 151USE | 3/8" FPT |
| 155USE | 3/8" MPT |
| 156USE | 3/8" Hose Barb |
| 3/8" BODY SIZE | |
| 582USE | 1/4" FPT |
| 583USE | 1/4" MPT |
| 585USE | 1/4" Hose Barb |
| 580USE | 3/8" FPT |
| 581USE | 3/8" MPT |
| 586USE | 3/8" Hose Barb |
| 584USE | 1/2" FPT |
| 587USE | 1/2" MPT |
| 588USE | 1/2" Hose Barb |
| 1/2" BODY SIZE | |
| 123USE | 3/8" FPT |
| 121USE | 3/8" MPT |
| 127USE | 3/8" Hose Barb |
| 120USE | 1/2" FPT |
| 122USE | 1/2" MPT |
| 128USE | 1/2" Hose Barb |
| 124USE | 3/4" FPT |
| 129USE | 3/4" MPT |
| 125USE | 3/4" Hose Barb |

* Please Note: In 3/8" and 1/2" body sizes, the Safety Exhaust Coupler works ONLY with the Industrial and Automotive Interchanges.

For high-vibration applications, we strongly recommend the use of a lead-in hose to lengthen the life of the coupler.




How the 5-in-1 Works

CONNECTING



To connect, plug is easily inserted into coupler under zero pressure.



Black sleeve is pulled down to start air flow.

VENTING



Black sleeve is pushed up to stop air flow and safely vent downstream pressure.

DISCONNECTING



Silver ring is pushed up to fully disconnect.