



RB401T-E



RB401T-E



ToolModel	PartNo	PartCode	Description
RB401T-E	1	RB70859	ARM A ASSY
RB401T-E	2	BB40481	BOLT 3X5
RB401T-E	3	AA71408	SCREW 3 X 3
RB401T-E	4	RB12633	WIRE GUIDE BASE
RB401T-E	5	RB70917	ARM A UNIT
RB401T-E	6	BB41714	BOLT 3X5 SG
RB401T-E	7	RB12636	WIRE GUIDE LEVER
RB401T-E	8	KK29117	COMPRESSION SPRING 9117
RB401T-E	9	RB70620	WIRE GUIDE UNIT
RB401T-E	10	FF41865	STEP PIN 1865
RB401T-E	11	JJ10113	E-RING 2.5
RB401T-E	12	BB40420	BOLT 4 X 16
RB401T-E	13	FF52115	HOLLOW PIN 2115
RB401T-E	14	EE39861	WASHER 4.3X9X1
RB401T-E	15	RB12865	FEEDING GEAR A
RB401T-E	16	FF51715	HOLLOW PIN 1715
RB401T-E	17	FF31559	PIN 1559
RB401T-E	18	RB12740	SHAFT COLLAR
RB401T-E	19	RB12653	CLUTCH B
RB401T-E	20	RB12651	CLUTCH A
RB401T-E	21	RB12652	FEEDING GEAR SHAFT A
RB401T-E	22	RB70700	FEEDING MOTOR BASE UNIT
RB401T-E	23	RB70627	FEEDING MOTOR
RB401T-E	24	JJ10514	E-RING 3 CF
RB401T-E	25	RB70625	FEEDING GEAR B UNIT
RB401T-E	26	RB12964	FEEDING GEAR SHAFT B
RB401T-E	27	RB70881	FEEDING GEAR BASE UNIT
RB401T-E	28	RB12963	SPRING BASE
RB401T-E	29	BB40824	BOLT 3X6
RB401T-E	31	RB12659	LEAF SPRING
RB401T-E	32	RB70667	WIRE GUDE C UNIT
RB401T-E	33	FF41867	STEP PIN 1867
RB401T-E	34	KK29119	COMPRESSION SPRING 9119
RB401T-E	35	RB81343	RELEASE LEVER A ASSY
RB401T-E	36	BB41715	BOLT 4X18 C
RB401T-E	37	EE11103	SPRING WASHER 2-4
RB401T-E	38	EE39825	WASHER 4.5X7.4X0.8
RB401T-E	39	RB12965	RELEASE LEVER A
RB401T-E	40	RB12683	RELEASE LEVER A CAP
RB401T-E	41	FF41869	STEP PIN 1869
RB401T-E	42	FF52120	HOLLOW PIN 2117
RB401T-E	43	CC42512	HEX NUT 1A M4
RB401T-E	44	FF41868	STEP PIN 1868
RB401T-E	45	RB12657	RELEASE LEVER B
RB401T-E	46	JJ10510	RETAINING RING 2.3
RB401T-E	47	RB12609	HOOK L
RB401T-E	48	RB12853	CARBIDE PIN 2.5X14.8
RB401T-E	49	RB12616	SLEEVE COVER
RB401T-E	50	FF21267	SPRING PIN 2X8
RB401T-E	51	RB12610	HOOK R
RB401T-E	52	RB12614	SLEEVE A

ToolModel	PartNo	PartCode	Description
RB401T-E	53	RB12712	KEY
RB401T-E	54	RB12611	CENTER HOOK
RB401T-E	55	FF31718	PARALELL PIN 1718
RB401T-E	56	RB12713	KEY B
RB401T-E	57	RB12612	SLEEVE GUIDE
RB401T-E	58	RB12615	SLEEVE B
RB401T-E	59	FF21234	W.S. PIN 3 X 12 CN65055
RB401T-E	60	RB12617	CUTTER RING
RB401T-E	61	RB12618	CUTTER RING GUIDE
RB401T-E	62	JJ21606	C-RING 15
RB401T-E	63	JJ80901	C-RING 11
RB401T-E	64	RB12714	BUMPER GUIDE
RB401T-E	65	RB12619	BUMPER
RB401T-E	66	EE39859	WASHER 11.1X23.4X2
RB401T-E	67	LL11756	BEARING 6803ZZ
RB401T-E	68	JJ21603	C-RING 20
RB401T-E	69	EE39865	WASHER 20X35X1
RB401T-E	70	LL41003	THRUST BEARING AXK1104
RB401T-E	71	RB12620	INTERNAL GEAR
RB401T-E	72	RB12720	D RING
RB401T-E	73	RB70699	TIP AXIS A UNIT
RB401T-E	74	RB70613	TWIST ASSY
RB401T-E	75	RB12622	PLANETARY GEAR
RB401T-E	76	RB70642	SUN GEAR UNIT
RB401T-E	77	RB12623	WASHER, TWIST AXIS
RB401T-E	78	RB70617	TWISTING MOTOR
RB401T-E	79	BB40425	BOLT 3X10
RB401T-E	80	FF51817	HOLLOW PIN 1817
RB401T-E	81	RB70684	MOTOR COVER UNIT
RB401T-E	82	EE32104	WASHER 2-3
RB401T-E	83	BB41302	BOLT 4X10 CF
RB401T-E	86	CC41104	HEX.NUT 1-3
RB401T-E	87	FF51710	HOLLOW PIN 1710
RB401T-E	88	CC49308	HEX. NUT M4
RB401T-E	89	RB12959	SPECIFICATION LABEL
RB401T-E	90	CC49508	NUT M5
RB401T-E	91	FF51714	HOLLOW PIN 1714
RB401T-E	92	RB81360	FRAME L ASSY (401T)
RB401T-E	93	RB81359	MAIN CIRCUIT BOARD UNIT (401T)
RB401T-E	94	RB12687	LABEL
RB401T-E	95	ZS00034	MAIN SWITCH (441)
RB401T-E	97	RB70843	SWITCH BASE ASSY (401T)
RB401T-E	98	RB70697	ELECTRODE UNIT
RB401T-E	99	AA05952	SCREW 2.6X10
RB401T-E	100	RB12674	MAGAZINE CAP
RB401T-E	101	RB70640	SENSOR CURCUIT BOARD F UNIT
RB401T-E	102	RB12673	MAGAZINE STOPPER SHAFT
RB401T-E	103	KK24186	COMPRESSION SPRING 4186
RB401T-E	104	RB12684	WIRE OPERATION LABEL
RB401T-E	105	JJ21601	C-RING 8
RB401T-E	106	FF52116	HOLLOW PIN 2116

ToolModel	PartNo	PartCode	Description
RB401T-E	107	RB81296	MAGAZINE UNIT
RB401T-E	109	EE39609	RUBBER WASHER 1.8X6X2
RB401T-E	110	KK34098	TORSION SPRING 4098
RB401T-E	111	FF43419	STEP PIN 3419
RB401T-E	112	RB12715	MAGAZINE PLATE
RB401T-E	113	RB12671	ROTARY SHAFT
RB401T-E	114	RB12672	MAGAZINE STOPPER
RB401T-E	115	FF21629	SPRING PIN 2X14
RB401T-E	116	RB81361	MAGAZINE COVER ASSY
RB401T-E	117	RB81299	MAGAZINE COVER UNIT
RB401T-E	118	AA05560	SCREW 3X12 CF
RB401T-E	119	HH14169	O-RING AS 568-003 1A
RB401T-E	120	EE39860	WASHER 5X2.6X1
RB401T-E	121	FF51713	HOLLOW PIN 1713
RB401T-E	122	RB12829	NOTICE LABEL
RB401T-E	123	KK34097	TORSION SPRING 4097
RB401T-E	124	RB12669	REEL PRESS
RB401T-E	125	FF31639	PARALELL PIN 1639
RB401T-E	126	RB70641	SENSOR CURCUIT BOARD G UNIT
RB401T-E	127	AA31724	SCREW 2X8
RB401T-E	128	RB12667	MAGAZINE COVER CAP
RB401T-E	129	RB12911	401T-E LABEL
RB401T-E	130	RB12639	CURL GUIDE B
RB401T-E	131	RB70864	CURL GUIDE A1 UNIT
RB401T-E	132	FF52121	HOLLOW PIN 2121
RB401T-E	133	RB70666	WIRE GUDE B UNIT
RB401T-E	134	RB12915	CURL GUIDE SHAFT
RB401T-E	135	KK34102	TORSION SPRING 4102
RB401T-E	136	RB12916	ARM C
RB401T-E	137	BB40810	BOLT 3X16
RB401T-E	138	RB12894	FIXED CUTTER
RB401T-E	139	RB12723	CON-ROD GUIDE B
RB401T-E	140	RB12721	CON-ROD COVER
RB401T-E	141	RB12722	CON-ROD GUIDE A
RB401T-E	142	RB12643	CUTTER
RB401T-E	143	RB12724	CON-ROD BASE
RB401T-E	144	FF51711	HOLLOW PIN 1711
RB401T-E	145	BB40717	BOLT 3X20 CF
RB401T-E	146	RB70682	ARM B UNIT
RB401T-E	147	EE39857	WASHER 3.2X11X1
RB401T-E	148	RB12637	ARM B
RB401T-E	149	EE39858	WASHER 3.2X7X1
RB401T-E	150	RB12645	CUTTER LEVER A
RB401T-E	151	RB12648	CUTTER PIN
RB401T-E	152	RB70683	CUTTER LEVER A UNIT
RB401T-E	153	RB12647	CUTTER SHAFT
RB401T-E	154	RB12649	CON-ROD
RB401T-E	155	RB12646	CUTTER LEVER B
RB401T-E	156	JJ10509	E-RING 4 CF
RB401T-E	157	KK33398	TORSION SPRING 3398
RB401T-E	158	RB70863	ARM B ASSY

ToolModel	PartNo	PartCode	Description
RB401T-E	161	RB12815	WINDOW
RB401T-E	166	RB12665	RELEASE BUTTON BASE
RB401T-E	167	RB12664	RELEASE STOPPER
RB401T-E	168	RB12662	RELEASE BUTTON
RB401T-E	169	KK33401	TORSION SPRING 3401
RB401T-E	170	RB12725	SPONGE
RB401T-E	172	RB12897	WARNING LABLE
RB401T-E	173	RB12661	BRAND PLATE
RB401T-E	174	BB40708	BOLT 5X25
RB401T-E	175	BB40716	BOLT 3X6 CF
RB401T-E	176	RB70848	FRAME R ASSY (401T)
RB401T-E	177	RB70616	JAW BASE ASSY
RB401T-E	178	RB12627	JAW B
RB401T-E	179	KK33249	TORSION SPRING 3249
RB401T-E	180	RB12625	JAW BASE
RB401T-E	181	FF41864	STEP PIN 1864
RB401T-E	182	RB12626	JAW A
RB401T-E	184	BB40404	HEX. BOLT 5X16 N10016
RB401T-E	185	RB70879	HARNESS UNIT
RB401T-E	186	BB41716	BOLT 3X4
RB401T-E	187	BB41717	BOLT 4X8
RB401T-E	188	FF31651	PARALELL PIN 1651
RB401T-E	189	KK24198	COMPRESSION SPRING 4198
RB401T-E	190	RB12919	COVER (401T)
RB401T-E	191	RB12929	CONTACT COVER L
RB401T-E	192	RB12930	CONTACT COVER R
RB401T-E	193	RB12935	LINK SPRING
RB401T-E	194	RB12936	ROTATING PIN
RB401T-E	195	RB70839	CONTACT SWITCH L ASSY
RB401T-E	196	RB70840	CONTACT SWITCH R ASSY
RB401T-E	197	RB70868	CURL GUIDE LINK UNIT
RB401T-E	200	BB40849	BOLT 4X6
RB401T-E	204	RB81357	CURL GUDE LINK ASSY
RB401T-E	206	FF31652	PARALELL PIN 1652
RB401T-E	207	FF31653	PARALELL PIN 1653
RB401T-E	208	FF41878	STEP PIN 1878
RB401T-E	209	JJ10109	E-RING 2
RB401T-E	210	JJ10512	E-RING 5
RB401T-E	211	RB12912	LABEL
RB401T-E	212	RB12946	HANDLE BASE R
RB401T-E	213	RB12947	HANDLE BASE COVER
RB401T-E	214	RB70844	HANDLE BASE L UNIT
RB401T-E	215	RB70895	HANDLE PIVOT UNIT
RB401T-E	219	RB12949	HANDLE BASE SHAFT
RB401T-E	220	RB12950	HANDLE BASE PLATE
RB401T-E	221	RB81365	HANDLE ASSY
RB401T-E	222	AA05589	SCREW 3X16
RB401T-E	223	BB40715	BOLT 3X12
RB401T-E	225	RB12910	PIPE LAVEL
RB401T-E	226	RB12945	SQUARE PIPE
RB401T-E	227	RB70900	LATCH UNIT

ToolModel	PartNo	PartCode	Description
RB401T-E	228	AA05572	SCREW 3X8
RB401T-E	229	BB41408	BUTTON SCREW 5X8
RB401T-E	230	RB12900	MAGAZINE STAY R
RB401T-E	231	RB12902	SEALING RUBBER
RB401T-E	232	RB70891	MAGAZINE STAY L
RB401T-E	233	BB41408	BUTTON SCREW 5X8
RB401T-E	234	RB12905	BODY SHAFT
RB401T-E	235	RB12906	BODY PLATE
RB401T-E	236	RB70850	SENSOR UNIT
RB401T-E	237	FF31723	PARALELL PIN 1723
RB401T-E	238	FF41879	STEP PIN 1879
RB401T-E	239	JJ10511	E-RING 3.2 CF
RB401T-E	240	RB70845	ARM ATTACHMENT ASSY(LONG)
RB401T-E	241	RB70907	ARM ATTACHMENT ASSY(SHORT)
RB401T-E	242	RB70875	CONTACT SENSOR